



MODULAR
SERVICES COMPANY

SPECIFICATIONS

BED DOCKER



The Modular Services Bed Docker is a UL Listed assembly which provides a “docking” location for the patient bed with electrical devices on each side. These devices will be as shown on the project drawings.

Services are segregated into compartments and all pre-installed devices are pre-wired to service termination locations, ready for connection to the incoming services being fed from the building wall behind.

The Bed Docker module incorporates 16-gauge steel housing for installation of the electrical devices. This housing is trimmed with a single piece, high-impact Kydex® cover. The standard color of the Kydex® cover is either “Surf” or “Platinum Grey.”



MODULAR
SERVICES COMPANY

500 E. Britton Rd. • Oklahoma City, OK 73114

Tel: 800.687.0938 • Fax: 405.528.0368

www.modularservices.com

info@modularservices.com